

MONARCH

Materials Group Inc.

Determining what size of cover you need:

1.) Locate the Monarch Materials Group Inc. sticker located in the center of your steel window well. (If you can't locate the sticker or if the well was produced by a different manufacturer skip to #2 below)



How to Interpret the Monarch Label:

#95707

AWL-SBII 4936-60

→ The first 5 digit number corresponds to the Monarch Materials Group Inc part number.

→ The next few letters correspond to the model of window well:

- SBII – Stif Back II®
- DS – Deluxe Straight
- ER – Economy Round
- ES – Economy Straight

→ The last set of numbers tell you the width (W), projection (P) and height (H) of your window well in that particular order. The window well in this example is 49" (W), 36" (P), and 60"(H) so for this well, you would need a 49"(W) x 36"(P) cover for a Stif Back II® window well. (Please note that all of our dimensions are the interior dimensions of the window well.)

If you are only able to locate our manufacturer number and cannot read the rest of the label, please refer to our catalog product pages to find the part number or contact us and we will help you determine what size of area well you have.

2.) If you have a home that wasn't recently built or if your window well isn't one of our standard sizes, please see our custom cover order form. You will need to complete the form and then contact Monarch Materials Group. We can help you determine what size of cover you will need and locate the nearest distributor in your area where you could purchase a cover.