

QUARRY VIEW BACKCAP

Fiberglass Window Well Backcap

Quarry View Backcap Installation Instructions

(Read the instructions completely before installing the Backcap.)

Materials & Tools Needed:

Warning: Use protective eyewear.

Hammer drill.

Socket or nut driver



Wedge Anchor 3/8"x 2-3/4"



- Masonry Anchors & Drill Bit.
- Marker

Extension Installation:

- 1. For a new installation, install the Quarry View Window Well per the standard instructions then install the Extension as follows.
- 2. Measure the width across the top of the installed Window Well and across the top of the Extension Cap verifying that they are within 2 in. of each other.
 - a) If they are not, you will have to "warm" the Extension Cap prior to installation by placing it under a black plastic tarp for at least 1 hour in direct sunlight prior to installation. (This will allow the Cap to be flexible enough to be worked up to 6 in of misalignment).
- 3. For new installation, when backfilling, leave 2 feet of clearance out and down from the top edge of the Well or for existing installations, dig a trench around the Window Well so that you have 2 feet of clearance out and down from the top edge of the Well.
- 4. Lift the Cap (requires at least 2 people) and approach the Well with the front (flanged) portion of the Cap angled down at about 30 degrees



- 5. Get the front edges of the Cap hooked over the top edge for the Well and begin lowering it down onto the Well, making sure that the hook on the Cap is engaging in the top of the Well.
- 6. At the back of the Well, the bottom edge of the Cap will have to be pulled outward as it is lowered over the step molded into the Well.

- 7. Verify that the Cap is firmly seated.
- 8. Anchor the Cap to the concrete wall by drilling and installing #2 (1/4" x 2 3/4") wedge anchors or Tapcons through the flange 3-4 inches from the top and bottom of the Cap on each side.
- 9. Backfill around the Window Well in 6-8" layers, being careful to prevent damage to the Cap.

