

MONARCH

Materials Group Inc.

THERMAL HINGE COVER®

Thermal Hinge Cover Installation Instructions


End User Notes: (Read the instructions completely before installing the cover).

- Thermal Hinge Covers do NOT fit on the area well exactly. They are designed to over hang each side to allow for ventilation.

Materials & Tools Needed:

Warning: Use protective eyewear.

- Tape Measure
- Masonry Drill Bit (5/32")
- Marker
- Level
- Impact Drill
- Tapcon® concrete screws, diameter \varnothing 3/16" & length \pm 1 1/4"



Thermal Hinge Cover Installation:

1. Position the cover over the window well
 - The cover should be square and equally spaced from side to side.
 - Position the back of the cover 1/4" above the top of the well.
2. Measure and mark the well
 - Mark the center point of the window well and equal points on each side
 - Holes should be 3/8" from top of hinge
 - Mounting requires at least three (3) mounting holes
 - **Note:** If larger than 49" wide, using four (4) mounting holes is recommended
3. Level the cover
 - Ensure the cover is level
 - Pre-drill holes into hinge mounting channel



4. Drill holes

- Drill through the hinge mount bracket into foundation or siding
- **Note:** Blow out holes to ensure no residue remains
- Using TapCons or Wood screws, fasten the Thermal Hinge Cover to foundation or siding



5. Assemble Hinge Prop and you're finished

- Push plastic cap on prop pin
- You can keep the Thermal Hinge Cover closed or allow for ventilation using the hinge props.

